



INTERFACE MODULE

The difference of the upper cover and the side part of the module shown on the top right corner.



DMG-02P DMG-03P DMG-04P
DMG-05P DMG-07P DMG-08P
DMG-09P DMG-14P DMG-17P
DMG-19P DMG-24P DMG-29P

CE 2.5mm²
UL 24-12AWG
Poles 2P,3P,4P,5P,7P,8P,9P,
14P,17P,19P,24P,29P



FMET-02P
FMET-03P FMET-04P
FMET-06P FMET-08P



FMET-04P-2100AH



FMET-02P-14-05AH



FMET-02P-11-25AH



FMET-02P-1Y-31AH



FMET-03P-14-04AH



FMET-03P-14-15AH



FMET-04P-14-05AH



FMET-04P-1Y-13AH



FMET-04P-11-26AH



FMET-06P-14-15AH



FMET-08P-11-14AH



FMET-02P-60A



FMET-03P-10A



FEGM-12P



FMED-02P



FMED-03P



FBUS17.5-11A



FBUS22.5-100A



DM72



DM72-100AH



DM100

CE 150V/7A
UL 150V/7A

CE 150V/7A
UL 150V/7A



DM108-100AH



DM108



DMK72



DMK108



DM50



DMGB-02P
DMGB-03P



FEG-02P
FEG-04P



FEGH-03P
FEGH-06P



FEGM-03P
FEGM-06P